

ATAPI COMMAND TABLE (in Alphabetic Order)

<i>ATAPI Command</i>	<i>Instruction</i>	<i>OP</i>
ATAPI RESET	ARST	08h
BLANK	Blank	A1h
CLOSE TRACK/SESSION	CloseTrk	5Bh
ERASE (10) SBC	Erase	2Ch
FORMAT UNIT	FmtUnit	04h
GET CONFIGURATION	GetCfg	46h
GET EVENT/STATUS NOTIFICATION	GetEvent	4Ah
GET PERFORMANCE	GetPerf	ACh
LOAD/UNLOAD MEDIUM	LOAD	A6h
MECHANISM STATUS	MechStatus	BDh
PAUSE/RESUME	Pause/Resume	4Bh
PLAY AUDIO (10)	PlayAudio	45h
PLAY AUDIO (12)	PlayAudio12	A5h
PLAY AUDIO MSF	PlayMsf	47h
PREVENT/ALLOW MEDIUM REMOVAL	PrevMed/AllowMed	1Eh
READ BUFFER CAPACITY	RdBufCap	5Ch
READ CD	RdCd	BEh
READ CD AND SAVE TO FILE	Rd10File	BEh
READ CD MSF	RdCdMsf	B9h
READ DISC INFORMATION	RdDiscInf	51h
READ DVD STRUCTURE	RdStruct	ADh
READ FORMAT CAPACITY	RdFmtCap	23h
READ HEADER	RdHeader	44h
READ SUBCHANNEL	RdSubChv	42h
READ TOC/PMA/ATIP	RdToc	43h
READ TRACK/RZONE INFORMATION	RdTrkInf	52h
REPAIR RZONE	RepairRzone	58h
REPORT KEY	RptKey	A4h
RESERVE TRACK/RZONE	ResTrk	53h
SEND CUE SHEET	SendCue	5Dh
SEND DVD STRUCTURE	SendDvdStruct	BFh
SEND EVENT	SendEvent	A2h
SEND KEY	SendKey	A3h
SEND OPC INFORMATION	SendOpc	54h
SET CD SPEED	SetCdSpeed	BBh
SET READ AHEAD	SetRdAhead	A7h
SET STREAMING	SetStream	B6h
STOP PLAY/SCAN	StopPlay	4Eh
WRITE (10) FROM FILE	Wr10File	2Ah
WRITE AND VERIFY (10) FROM FILE	WrVfy10File	2Eh